



CTEKCloud

Unified Communications

Using A Bluetooth Headset with a Yealink Device

To activate the Bluetooth mode:

1. Press Menu >Basic >Bluetooth.
2. Press < or > , or the Switch soft key to select On from the Bluetooth field.
3. Press the Save soft key to accept the change.

You can verify this by checking for the Bluetooth Icon on the phone.

To deactivate the Bluetooth mode:

1. Press Menu >Basic >Bluetooth.
2. Press < or > , or the Switch soft key to select Off from the Bluetooth field.
3. Press the Save soft key to accept the change.

The Bluetooth icon should be gone.

To pair and connect your Bluetooth headset to your phone:

First make sure that your headset is in pairing mode.

1. Press Menu >Basic >Bluetooth.
2. Press the Scan soft key to search the Bluetooth devices.

The screen should show "Scanning". Once the device has been found it will display on the screen.

3. Select the desired Bluetooth headset and press Connect soft key.

4. Enter the PIN in the Password field.

The default PIN is usually “0000” or “1234”.

5. Press the OK soft key.

The device should now be paired with your phone.